



Basic diagram connection for convectors KORAWALL Direct; WVD  
Heating or light cooling



Description

- ① - control touchpad for fan RPM heating/cooling
- ② - control unit
- ③ - power supply 230 V AC/24 V DC
- ④ - supply connector
- ⑤ - tangential low-energy EC fan assembly
- ⑥ - regulation fitting connection – LM valve
- To - temp sensor (room)
- Tv - temp sensor (water)



Fan speed	LED	Fan RPM
0	○ ○ ○ ○ ○	0 – Off
1	● ○ ○ ○ ○	1 – Min
2	● ● ○ ○ ○	2 – Low
3	● ● ● ○ ○	3 – Medium
4	● ● ● ● ○	4 – High
5	● ● ● ● ●	5 – Max